

2~8℃ Intellect Vaccine Freezer AE-C8V70ZT

Digital vaccine storage and management at 2~8℃.

Secure 2~8℃ vaccine storage with integrated digital monitoring and traceability.



KEY CAPABILITIES



Digital vaccination UI

10.1-inch control UI for vaccination information display and interaction.



Integrated management

Integrates queuing, personnel and vaccine identification, in/out storage management, and cold chain monitoring.



Pop-out drawers

Multiple independent pop-out drawers enable quick access and reduce internal/external air convection.



Five-level alarm

High/low temperature, sensor fault, door ajar, and power failure alarms via buzzer, light, and notifications.



Partitioned storage

Separate drawers for different vaccines; scanning recipient identity opens corresponding drawer automatically.



Emergency unlocking

Mechanical emergency unlocking equipped; UPS power supply optional to enable retrieval during outages.



Unified compatibility

Compatible with provincial immunization program platforms; integrates IoT, big data, AI, and edge computing.

APPLICATIONS



Immunization Clinics

Secure storage of vaccines for routine immunization services.



Community Health Centers

Reliable 2~8℃ storage for vaccines in community immunization programs.



Disease Control Centers

Centralized vaccine storage with digital monitoring and traceability.

Product model

Parameter	AE-C8V70ZT
Voltage range (V)	187~242
Storage temperature (℃)	2~8
Width×depth×height (external) (mm)	600×625×940
Capacity (L)	70
Net weight (kg)	80
Number of drawers	4



Website:
<https://aelabgroup.com/>



Email:
info@aelabgroup.com



WhatsApp:
[+8615800016110](https://wa.me/8615800016110)